


How to Install Encoder Drivers


1. On the bottom of the encoder, ensure the label reads *USB Prokee* (or *Smartcard*) *Encoder, ARM 7*. If this is not the case, please contact the Syntech Customer Satisfaction Center for replacement.




2. Open the FuelMaster Plus software (software).
3. Click the **About** button.




- a. If your version of software is 5.26.3.0 or newer, close the software.
- b. If your version of software is older than 5.26.3.0, click the **Config** button and ensure the encoder type is set to *USB*. Afterwards, close the software.




4. Open a File Explorer window and browse to the *C:\Program Files (x86)\Syntech\FuelMaster Plus* folder.




5. Create a folder named *Signed Encoder Drivers*.




6. Copy the encoder driver files downloaded from myfuelmaster.com into this folder.
7. Open the *Computer Management* app. This may need to be run as administrator to install drivers.




8. On the left side, select **Device Manager**.




9. Under the *Other devices* section, find and select the SYN-TECH EN-PR 200 or SYN-TECH EN-SC 200.




10. Select the **Update Driver** button.




11. Select **Browse my computer for drivers**.




12. Select **Browse...**




13. Browse through the folder levels to find the path from Step 5, then click **OK**.



14. Click **Next**.



15. Your computer may ask you to verify the driver installation, but when done, you should see that the driver has been installed successfully.



16. You may now open your software and encode keys or smartcards.